

HOW TO INITIALIZE THE BLU-RAY DISC PLAYER

To put the program back at the factory-default, initialize the BD player as the following procedure.

Note:

- By initializing, network is reset to disconnected state and “Network Service Disclaimer” appears on the screen.
- Once the unit is initialized, the unit starts from Initialization the next time it is turned on. The Initialization allows quick set up of language and network settings. To exit this mode, select “Cancel” on the screen.

1. Turn the power on.
2. Remove the disc on the tray and close the tray.
3. Press [▶▶] (skip up), [1], [2], and [3] buttons on the remote control unit in this order.
Fig. a appears on the screen.

"*" differ depending on the models.




Fig. a

4. Press [■] button on the remote control unit.
Fig. b appears on the screen.

"*" differ depending on the models.




Fig. b


5. After initializing, the power will turn off automatically.

FIRMWARE RENEWAL MODE

Note: The file extension of the available firmware is "b42".

1. Turn the power on and remove the disc on the tray and close the tray.
2. Press [▶▶] (skip up), [6], [5], and [4] buttons on the remote control unit in this order.
Fig. a appears on the screen.

"*" differ depending on the models.



The available software update mode will differ depending on the model type.

Fig. a Version Up Mode Screen (Example)

3. Select "Disc" or "USB" or "SD Card" and press [OK] button on the remote control unit.
4. Insert the disc or USB Memory Stick or SD Card for version up.
5. The BD player enters the F/W version up mode automatically. Fig. b will appear on the screen. Make sure to insert the proper F/W for the state of this model.

"*" differ depending on the models.




Fig. b Programming Mode Screen (Example)

The appearance shown in (*1) of Fig. b is described as follows:

No.	Appearance	State
1	Loading Disc	Loading the disc
2	Reading...	Sending files into the memory.
3	See LED.	Writing new version data, the progress will be displayed as shown in Fig. c.

"*" differ depending on the models.




Fig. c Version Up Mode

6. After the update, the power will turn off automatically.
7. The power turns back on automatically. Remove the disc or USB Memory Stick or SD Card from the unit.

Note: All the settings will be put back to factory-default.

The following USB Memory Stick/SD Card can be used for software update. Make sure to use a device that has enough space.

- USB Memory Stick (FAT16/FAT32 file system)
- SD/Mini SD/Micro SD Card (FAT12/FAT16 file system)
- SDHC/Mini SDHC/Micro SDHC Card (FAT32 file system)

How to Verify the Firmware Version

1. Turn the power on.
2. Remove the disc on the tray and close the tray.
3. Press [▶▶] (skip up), [1], [2], and [3] buttons on the remote control unit in this order.
Fig. d appears on the screen.

"*" differ depending on the models.




Fig. d

4. To exit this mode, press [⏏] button.

FIRMWARE RENEWAL MODE (for User)

Disc/USB Memory Stick/SD Card Update

1. Press [HOME] button to display Setup menu.
2. Select Settings - Others - Software Update.
3. Select the software update mode from "Disc" or "USB Memory Stick" or "SD Memory Card." The available software update mode will differ depending on the model type.
4. The screen appears in Fig. e when "Yes" is chosen. Insert the disc or USB Memory Stick or SD Card for software update.




Fig. e (Example of Disc mode)

5. Disc loading starts. Fig. f will appear on the screen.




Fig. f (Example of Disc mode)

6. Fig. g will appear on the screen, then select "Yes".




Fig. g

7. Firmware loading starts. Fig. h will appear on the screen.




Fig. h

8. Updating starts automatically. Fig. i will appear on the screen.




Fig. i (Example of Disc mode)

9. The power turns off automatically.
10. The power turns back on automatically. Remove the disc or USB Memory Stick or SD Card from the unit.

Note: The setup setting configured before the update will be kept.

The following USB Memory Stick/SD Card can be used for software update. Make sure to use a device that has enough space.

- USB Memory Stick (FAT16/FAT32 file system)
- SD/Mini SD/Micro SD Card (FAT12/FAT16 file system)
- SDHC/Mini SDHC/Micro SDHC Card (FAT32 file system)

Network Update

1. Press [HOME] button to display Setup menu.
2. Select Settings - Others - Software Update - Network.
3. When "Yes" is chosen, the screen appears in Fig. j and the unit starts connecting to the network.




Fig. j

4. The firmware version confirmation screen (Fig. k) will appear on the screen. Select "Yes" and press [OK] button.




Fig. k

5. Firmware downloading starts.
6. Upon completion of downloading, Fig. l will appear on the screen. Press [OK] button.




Fig. l

7. The unit starts reading the firmware. Fig. m will appear on the screen.




Fig. m

8. Updating starts automatically. Fig. n will appear on the screen.




Fig. n

9. The power turns off automatically.
10. The power turns back on automatically.

Note: The setup setting configured before the update will be kept.

Network Error Message

No.	Error Message
1	The cable is not connected. Please confirm the connection of the cable.
2	DHCP cannot be acquired. Please confirm connection or set it with the manual operation.
3	Internet Protocol address is not set. Please confirm the set content.
4	The equipment with same Internet Protocol address already exists. Please set another Internet Protocol address.
5	There is no response from Default gateway. Please confirm the address of Default gateway.
6	It is not possible to connect to the DNS server. Please confirm the Internet connection or the DNS address setting.
7	It is not possible to connect to the server. Please contact our support center.
8	It is not possible to confirm the software version. Please contact our support center.
9	Cannot connect to the wireless network. Please confirm the wireless network setting.

ERROR MESSAGE

Note: Only error messages for the unit's corresponding media will appear.



Error	Message
Disc Error	Disc Error - - Please eject the disc. - - Playback feature may not be available on this Disc.
Loader Error	Loader Error The unit stopped automatically due to loader error. Please open the disc tray once and then close it.
Parental Lock Error	Parental Lock On The current selected parental level prohibits playback.
Region Error	Region Error Playback is not authorized in your region. Region code of this disc :
The device connected for HDMI connection does not support HDCP.	(There is no message.)
USB Error	Memory Device Error - - Please check the Memory Device. - - There is no playback file on the Memory Device or Device has incorrect/ no format.
BD-Live Network Connecting Error	BD-Live Setting Error Network connection is interrupted. Please confirm "BD-Live Setting".
LAN Cable Not Connected	The cable is not connected. Please confirm the connection of the cable.
Cannot Acquire DHCP Server	DHCP cannot be acquired. Please confirm connection or set it with the manual operation.
Cannot Acquire IP Address	Internet Protocol address is not set. Please confirm the set content.
Already Existing IP Address	The equipment with same Internet Protocol address already exists. Please set another Internet Protocol address.
No Response From Default Gateway	There is no response from Default gateway. Please confirm the address of Default gateway.
Cannot Connect To DNS Server	It is not possible to connect to the DNS server. Please confirm the Internet connection or the DNS address setting.
Cannot Connect To Server	It is not possible to connect to the server. Please contact our support center.
Cannot Confirm Firmware Version	It is not possible to confirm the software version. Please contact our support center.

Error	Message
Firmware Update Error (Update File Error)	Error detected. File may be corrupted. Please download software again.
	Error detected. Please confirm whether it is USB device that corresponds to software update.
Cannot Connect To Download Server	It is not possible to connect to the server. Please contact our support center.
USB Error	Error in the USB Connection. USB operation has been stopped automatically. Please remove the USB device and restart the unit.

HOME NETWORK (DLNA) ERROR CODE

Error Code appears in the error screen when the unit detects an error, as shown below. The code is used to specifically determine the cause of error.




Fig. 1: Error Code (Example)

Error Code are displayed with "NE[*****]" ("*" is error code) as shown above.

Error Code Form

In the Home Network (DLNA), Error Code are used as follows.



Fig. 2

"Summary Error Code" are shown in the list below.

Summary Error Code	Error message
02	Cannot connect to server. Please check your settings.
03	Playback Error
05	No playable files found.
20	System Error
21	Unable to display files from the server. Please check server settings.
22	List Updated.
23	Connection with server lost.
24	Unable to connect to more than 10 servers. Please turn off or stop broadcasting 1 or more servers.

Detailed Error Code table (DLNA – HTTP Status Code)

Status Code	Description
201 Created	A new resource was created by this unit's request.
202 Accepted	This unit's request was accepted but its processing is not completed.
204 No Content	Though the server processed the request, there was no content.
205 Reset Content	No content.
300 Multiple Choices	<ul style="list-style-type: none"> • There are multiple choices. • The server could not determine its response. • Requested information contains multiple representations. This status is handled as Redirection by default and complies with the content of Location HEAD related to this response.
301 Moved Permanently	<ul style="list-style-type: none"> • Moved Permanently. • Requested resource has been assigned to a new permanent URI (Uniform Resource Identifier). Any future references to this source must use one of the returned URIs. • Indicates that requested information is moved to the URI specified by the Location HEAD. When this status is received, the default action is tracking the Location HEAD related to the response. When the original request method is POST, the redirected request will use GET.
302 Found	<ul style="list-style-type: none"> • Found. • Requested resource resides temporarily under a different URI.(Uniform Resource Identifier) • Indicates that requested information exists in the URI specified by the Location HEAD. When this status is received, Location HEAD related to the response will be tracked by default. When the request method is POST the redirected request will use GET.
303 See Other	<ul style="list-style-type: none"> • See other. • The response to the request can be found under a different URI (Uniform Resource Identifier) and to get this response, GET HTTP method will be used. • As a result of POST, client will be automatically redirected to the URI specified by the Location HEAD. GET will be used for requesting to a resource specified by the Location HEAD.
304 Not Modified	This unit caches the latest resource and the requested resource is not modified. (exception protocol error)
305 Use Proxy	<ul style="list-style-type: none"> • Proxy will be used. • The requested resource must be accessed through the proxy specified by the Location field. • Indicates that request must use the URI given by the Location HEAD to use the proxy server.
400 Bad Request	The server could not understand this unit's request.
401 Unauthorized	Indicates that the resource requested by this unit requires authentication.
403 Forbidden	The server received this unit's request, but refused to fulfill it.
404 Not Found	The requested URI was not found.
405 Method Not Allowed	<ul style="list-style-type: none"> • The method is not allowed. • The HTTP behavior used is not allowed. • Indicates that request method (POST or GET) is not allowed by the requested resource.
406 Not Acceptable	<ul style="list-style-type: none"> • The client could not find an acceptable response. • Indicates that the client specifies not to accept arbitrary representation for Accept header which could be used by the resource.
407 Proxy Authentication Required	<ul style="list-style-type: none"> • Proxy authentication is required. • Indicates that the requested proxy will request authentication. Proxy-authenticate header contains the detailed method for authentication.
408 Request Timeout	<ul style="list-style-type: none"> • While waiting for request, the server timed out. • Indicates that the client did not send a request within the expected time by the server.

Status Code	Description
409 Conflict	<ul style="list-style-type: none"> • There is a conflict. • The server timed out while waiting for a request. • Indicates that the client did not send a request within the expected time by the server.
410 Gone	<ul style="list-style-type: none"> • No longer available. • The requested resource could not be found at the server and forwarding address is unknown. • Indicates that requested resource is no longer available.
411 Length Required	<ul style="list-style-type: none"> • Length required. • The server refused to accept the request where Content-Length was undefined. • Indicates Content-length header is not defined.
412 Precondition Failed	<ul style="list-style-type: none"> • Fails to fulfill precondition. • The precondition in one or more of the requested header field has been tested false by the server. • The precondition given in the request could not be fulfilled and the request failed. Precondition can be set using If-Match, If-None-Match, If-Unmodified-Since request header.
413 Request Entity Too Large	<ul style="list-style-type: none"> • The requested entity is too large. • The server refused to process the request since the requested entity is larger than the server is willing or able to process. • Indicates that the request is too large for the server to process.
414 Request-URI Too Long	<ul style="list-style-type: none"> • The Request-URI is too long. • The server refused to process the request because the request URI (Uniform Resource Identifier) is too long for the server to interpret. • Indicates that the URI is too long.
415 Unsupported Media Type	<ul style="list-style-type: none"> • The media type is not supported. • The server refused to process the request because the format of request entity is not supported by the requested resource for the requested method. • Indicates the requested format is not supported.
500 Internal Server Error	Internal server error occurred.
501 Not Implemented	The server does not support functionalities required to process the request from this unit.
502 Bad Gateway	The proxy server between this unit and the server received an invalid reply from another proxy or the original server.
503 Service Unavailable	<ul style="list-style-type: none"> • Service is unavailable. • The service is temporarily overloaded. • Because of overloading or maintenance, the server is temporarily unavailable.
504 Gateway Timeout	<ul style="list-style-type: none"> • Gateway timed out. • While waiting for gateway, the request timed out. • Indicates that the intermediate proxy server has timed out while waiting for a response from another proxy or original server.
505 Version Not Supported	<ul style="list-style-type: none"> • The version is not supported. • The server refuses or does not support the version of protocol given in the request message. • Indicates that requested version is not supported by the server.

Detailed Error Code table (DLNA – Application Status Code)

Status Code	Description
001 Nothing List	As a result of list creation process, there is no item to be displayed from the received data.
010 LAN Disconnect	This unit's LAN is disconnected.
020 Application Status Error	Error was detected in the DLNA application's internal state.
021 Application Status Error	Error was detected in the DLNA application's internal state.
022 Application System Error	Error was detected in the DLNA application system.

Status Code	Description
023 Unsupported Audio Format	An unsupported audio format was discovered.
024 Server Number Over Limit	Discovered server numbers over limit.
025 Changed List	The contents list currently displayed has been updated.
026 Disconnected Server	The original server of the displaying contents list has been disconnected.
027 Application System Error	Error was detected upon start of DLNA application.
600 Disconnected Server	The original server of the contents has been disconnected.
601 Not Exist Content	Content does not exist.
602 Critical Error	System error.
603 Changed List	The contents list has been updated at the server.
620 Not Exist Content	Image content does not exist.
621 Get failure	Image data get error. (an error other than HTTP status and under 500s)
622 File Open Error	Image data working file open error.
623 File Read Error	Image data working file read error.
624 File Close Error	Image data working file close error.
625 Decode mode Error	Image data decode mode error.
626 Header Error	Image data header error.
627 Struct Error	Image data header structural error.
628 Decode Error	Image data decode error.
629 Unsupported Format	Unsupported format.
630 Unsupported Size	Unsupported data size.
631 Attach Error	Shared memory attach error.
632 Dettach Error	Shared memory detach error.
633 Server Time Out Error	Server timed out.
640 File Read Error	File read error.
641 Unsupported Format	Unsupported Format.
642 No Change Decode Frame	No updates of decode frame.
643 Stream Get Error	Stream get error.
660 File Read Error	File read error.
661 Unsupported Format	Unsupported format.
662 Video Analyze Error	Video analyze error.
663 Audio Analyze Error	Audio analyze error.
664 1sec Offset Get Error	1sec offset get error.
665 Address Search Error	Address search error.
680 RFS_EVENT_SOCKET_ERROR	Socket error.
681 RFS_EVENT_HTTP_RES_SERVER_REFUSED	Server refusal notification.
682 RFS_EVENT_HTTP_RES_NOT_FOUND	The specified contents could not be found.
683 RFS_EVENT_HTTP_RES_SERVER_ERROR	Server error.

Status Code	Description
684 RFS_EVENT_HTTP_RES_UNEXPECTED_CODE	Unexpected status code.
685 RFS_EVENT_HTTP_RES_RANGE_NOT_SATISFIABLE	The specified range is not satisfiable.
686 RFS_EVENT_RECV_TIMEOUT	Timed out while waiting for response.
687 RFS_EVENT_DTCP_ERROR	RCVC internal error. (DTCP originated)
688 RFS_EVENT_DTCP_CONNECT_ERROR	DTCP connection error.
689 RFS_EVENT_DTCP_KEY_MNG_ERROR	Kx key error.
690 RFS_EVENT_RESPONSE_DATA_ERROR	Received message is invalid.
691 RFS_EVENT_SYSTEM_ERROR	RCVC internal error.
692 RFS_EVENT_TCP_DISCONNECTED	The TCP connection has been disconnected by the server during streaming.
693 RFS_EVENT_CONNECT_TIMEOUT	Time out occurred while establishing TCP connection.
694 RFS_EVENT_RECV_ERROR	Could not receive contents.
700 Refresh Error	Failed to update server list.
701 Disconnected Server	The server has been disconnected while displaying contents list.
702 Server Not Found	The server has been disconnected while getting contents list.
703 Server Info Error	Failed to get server information while getting contents list.
704 Contents List Error	Failed to get contents list.
705 Server Config Error	Failed to configure server.
706 List Not Found	Failed to get contents list.
707 Changed List	Displayed contents list has been updated.
708 Object Not Found	Neither folders or playable contents was found.
709 Object Not Found By Filter	Playable contents was not found by filter.
710 Object Count Zero	Nothing was found in the folder.
711 ILLEGAL Server Info	The contents information from the server is invalid.
712 ILLEGAL Total Count	The total counts of contents from the server is invalid.
713 Folder not Exist	The specified folder does not exist. (The current contents list displayed has been updated)
714 Critical Error	An error occurred on the system.